



INSTRUCTIONS FOR ERECTION OF PORTABLE CATTLE YARDS

1. Undoing the chains that secure to the ramp sides unloads panels. When travelling any real distance it is advisable to tie chains with a piece of wire around hooks in case chains become unhooked during transit.
2. As the yards can be formed into many shapes you have an idea of what you are going to use them for, such as veterinary work, just holding for loading etc, then you will be able to erect your yard to the shape you need.
3. Have your holding pins ready for slipping in lugs as you erect your race or panels together.
4. **Where you intend to use all facilities**, start at the ramp end and connect the 2ft gates into the ramp making sure that the gates hinge from the back of ramp.
5. Stand up bail head and connect to the 4ft gates.
6. If you have crush sides in your order connect them to the bail head making sure the operating lever for bail gate is on the right if you are standing in the crush looking up the ramp.
7. Your next step is to pick up the double posts and connect them to the side gates. The sliding track and sliding gates can now be fitted by taking out the two long bolts at the top and lifting the track into position and re inserting the bolts, the sliding gate hangs on the track and runs on nylon rollers. Put the first roller in and lift the gate up, you can rest your foot under the bottom of the gate and insert the second roller and bolt.
8. Connect two more panels in, making sure that the straps are on the outside of the race.
9. Insert hoop in next the same way.
10. Depending on the size of the yard you have, panels and gates can now be erected to your desired configuration

For more information regarding configuration please look in the Steer Portable Cattle Yard Brochure or on our web site www.steeraust.com.au

