

STEER PORTABLE SHEEP YARDS

Safety Warning:

Handling of livestock can be dangerous and extreme care should be taken. Only trained operators should use livestock handling equipment. This unit is not suitable for on highway use.

INSTRUCTIONS FOR USE.

1. Transport sheep yards to site.
2. Ensure yards are sited on a flat level site with 3.0mt clear access around the drafting race.
3. Yard panels should be unloaded and set up clear of the drafting race.
4. Remove safety chains around panels.
5. All panels are loaded with the panel straps on the outside for ease of erection.
6. Study the layout plans and begin to position panels in desired layout.
7. Panels on the drafting race should be adjusted to ensure they are **“Inward leaning”** at the top. This will prevent the panels from falling over.
8. Once all panels are removed the drafting race may be setup.
9. To lower race un-clip safety pins, bolts Marked **“A”** and remove.
10. Move retainer bracket around to clear A-Frame. Repeat on other side of race.
11. Stand clear as A-Frame raises about 500mm.
12. With 2 hands raise A-Frame to the vertical position and lock slide bar Marked **“B”** into position.
13. Attach panels to drafting race.
14. Yards are now ready for use.

Packing up.

1. This is a reverse of steps 11 to 1.
2. Ensure all panels are facing with the strip outwards for safe storage and transport. Make sure safety chains are attached.

This unit is not suitable for on highway use.

LAY OUTS FOR PORTABLE SHEEP YARDS

